

KENWOOD

STEREO CASSETTE TAPE DECK

KX-7050

KX-7050S

INSTRUCTION MANUAL

KENWOOD CORPORATION

Introduction

Your choice of this product indicates that you are a devotee to excellence in sound reproduction.

We appreciate your patronage and take pride in the long tradition of quality components that our company represents.

So that you can get the most out of your unit, we suggest that you take the time to read through this manual before you hook up and operate your system. This will acquaint you with operating features and system-connection considerations so that your listening pleasure will be enhanced right from the start. You will notice that in all aspects of planning, engineering, styling, operating convenience and adaptability we have sought to anticipate your needs and desires.

Keep this manual handy for future reference.

For your records

Record the serial number, found on the back of the unit, in the spaces designated on the warranty card, and in the space provided below. Refer to the model and serial numbers whenever you call upon your dealer for information or service on this product.

Model _____ Serial Number _____

Unpacking

Unpack the unit carefully and make sure that all accessories are put aside so they will not be lost.


Examine the unit for any possibility of shipping damage. If your unit is damaged or fails to operate, notify your dealer immediately. If your unit was shipped to you directly, notify the shipping company without delay. Only the consignee (the person or company receiving the unit) can file a claim against the carrier for shipping damage.

We recommend that you retain the original carton and packing materials for use should you transport or ship the unit in the future.

WARNING NOTICE:

IN MOST CASES IT IS AN INFRINGEMENT OF COPYRIGHT TO MAKE COPIES OF TAPES OR DISCS WITHOUT THE PERMISSION OF THE COPYRIGHT OWNERS. ANYONE WISHING TO COPY COMMERCIALY AVAILABLE TAPES OR DISCS SHOULD CONTACT THE MECHANICAL COPYRIGHT PROTECTION SOCIETY LIMITED OR THE PERFORMING RIGHTS SOCIETY LIMITED.

Dolby noise reduction and HX Pro headroom extension manufactured under license from Dolby Laboratories Licensing Corporation. HX Pro originated by Bang & Olufsen.

"DOLBY", the double-D symbol  and "HX PRO" are trademarks of Dolby Laboratories Licensing Corporation.

Accessories

Audio cord 2




System control cord..... 1
(Except for the U.K. and Europe)



AC plug adaptor..... 1
(Except for the U.S.A., Canada, Europe, U.K., Australia.)

For the unit with a European AC plug in areas other than Europe.



Contents

Caution: Read the pages marked  carefully to ensure safe operation.

Introduction.....	2	DPSS operations	12
▲ Before applying power	3	How to record	14
▲ Safety precautions.....	3	Synchro recording	17
▲ IMPORTANT SAFEGUARDS	4	Recording of CD playback.....	19
Before operation	6	Timer operations	21
Controls and indicators.....	7	Remote control operation (optional)	23
System connections.....	8	In case of difficulty	24
Listening to cassette tapes.....	10	Specifications	26

Before applying power

 **Caution:** Read this page carefully to ensure safe operation.

For the U.S.A. and Canada

Important!

Units shipped to the U.S.A. and Canada are designed for operation on **120** volts AC only.

For Australia and Europe

Important!

Units shipped to Australia are designed for operation on **240** Volts AC only.
Units shipped to Europe are designed for operation on **230** Volts AC only.

For the United Kingdom

Important!

Units shipped to the U.K. are designed for operation on **240** volts AC only.

Factory fitted moulded mains plug

1. The mains plug contains a fuse. For replacement, use only a 13-Amp ASTA-approved (BS1362) fuse.
2. The fuse cover must be refitted when replacing the fuse in the moulded plug.
3. Do not cut off the mains plug from this equipment. If the plug fitted is not suitable for the power points in your home or the cable is too short to reach a power point, then obtain an appropriate safety approved extension lead or adapter, or consult your dealer.
If nonetheless the mains plug is cut off, remove the fuse and dispose of the plug immediately, to avoid a possible shock hazard by inadvertent connection to the mains supply.

For other countries

Important!


Units shipped to countries other than the above countries are equipped with an AC voltage selector switch on the rear panel. Refer to the following paragraph for the proper setting of this switch.

AC voltage selection


This unit operates on **110 - 120** volts or **220 - 240** volts AC. The AC voltage selector switch Type A or Type B on the rear panel is set to the voltage that prevails in the area to which the unit is shipped. Before connecting the power cord to your AC outlet, make sure that the setting position of this switch matches your line voltage. If not, it must be set to your voltage in accordance with the following direction.

AC voltage selector switch

Type A



Type B








Move switch lever to match your line voltage with a small screwdriver or other pointed tool.

Note:

Our warranty does not cover damage caused by excessive line voltage due to improper setting of the AC voltage selector switch.

Safety precautions

WARNING: TO PREVENT FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

  	CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE, REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.
	THE LIGHTNING FLASH WITH ARROWHEAD SYMBOL, WITHIN AN EQUILATERAL TRIANGLE, IS INTENDED TO ALERT THE USER TO THE PRESENCE OF UNINSULATED "DANGEROUS VOLTAGE" WITHIN THE PRODUCT'S ENCLOSURE THAT MAY BE OF SUFFICIENT MAGNITUDE TO CONSTITUTE A RISK OF ELECTRIC SHOCK TO PERSONS.
	THE EXCLAMATION POINT WITHIN AN EQUILATERAL TRIANGLE IS INTENDED TO ALERT THE USER TO THE PRESENCE OF IMPORTANT OPERATING AND MAINTENANCE (SERVICING) INSTRUCTIONS IN THE LITERATURE ACCOMPANYING THE APPLIANCE.

IMPORTANT SAFEGUARDS




Caution: Read this page carefully to ensure safe operation.


Please read all of the safety and operating instructions before operating this appliance. Adhere to all warnings on the appliance and in the instruction manual. Follow all the safety and operating instructions. These safety and operating instructions should be retained for future reference.

- 1. Power sources** – The appliance should be connected to a power supply only of the type described in the instruction manual or as marked on the appliance. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For appliances intended to operate from battery power, or other sources, refer to the instruction manual.
- 2. Power-cord protection** – Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, pay particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.

Never pull or stretch the cord.




- 3. CAUTION – Polarization** – This appliance may be equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.
- 4. Ventilation** – Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the appliance and to protect it from overheating, and these openings must not be blocked or covered. The appliance should be situated so that its location or position does not interfere with its proper ventilation.
To maintain good ventilation, do not put records or a tablecloth on the appliance. Place the appliance at least 10 cm away from the walls.
Do not use the appliance on a bed, sofa, rug or similar surface that may block the ventilation openings. This appliance should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.




- 5. Water and moisture** – The appliance should not be used near water - for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool, etc.

- 6. Temperature** – The appliance may not function properly if used at extremely low, or freezing temperatures. The ideal ambient temperature is above +5°C (41°F).
- 7. Heat** – The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.
- 8. Electric shock** – Care should be taken so that objects do not fall and liquid is not spilled into the enclosure through openings. If a metal objects, such as a hair pin or a needle, comes into contact with the inside of this appliance, a dangerous electric shock may result. For families with children, never permit children to put anything, especially metal, inside this appliance.



- 9. Enclosure removal** – Never remove the enclosure. If the internal parts are touched accidentally, a serious electric shock might occur.




- 10. Magnetic fields** – Keep the appliance away from sources of magnetic fields such as TV sets, speaker systems, radios, motorized toys or magnetized objects.
- 11. Cleaning** – Unplug this appliance from the wall outlet before cleaning. Do not use volatile solvents such as alcohol, paint thinner, gasoline, or benzine, etc. to clean the cabinet. Use a clean dry cloth.
- 12. Accessories** – Do not place this appliance on an unstable cart, stand, tripod, bracket, or table. The appliance may fall, causing serious injury to a child or adult, and serious damage to the appliance. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the appliance. Any mounting of the appliance should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.



13. Lightning – For added protection for this appliance during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the appliance due to lightning and power-line surges.

14. Abnormal smell – If an abnormal smell or smoke is detected, immediately turn the power OFF and unplug the appliance from the wall outlet. Contact your dealer or nearest service center.

POWER OFF!




15. Damage requiring service – The appliance should be serviced by qualified service personnel when:

- A.** The power-supply cord or the plug has been damaged.
- B.** Objects have fallen, or liquid has been spilled into the appliance.
- C.** The appliance has been exposed to rain or water.
- D.** The appliance does not appear to operate normally by following the instruction manual. Adjust only those controls that are covered by the instruction manual as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the appliance to its normal operation.
- E.** The appliance has been dropped, or the enclosure damaged.
- F.** The appliance exhibits a marked change in performance.


16. Servicing – The user should not attempt to service the appliance beyond that described in the instruction manual. All other servicing should be referred to qualified service personnel.

17. Outdoor antenna grounding – If an outside antenna is connected to the appliance, be sure the antenna system is grounded so as to provide some protection against voltage surges and built up static charges. Article 810 of the National Electrical Code ANSI/NFPA 70, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode. See Figure.



18. Power lines – An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

19. AC outlets – Do not connect other audio equipment with a power consumption larger than that specified to the AC outlet on the rear panel. Never connect other electrical appliances, such as an iron or toaster, to it to prevent fire or electric shock.



20. Overloading – Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

21. Attachment – Do not use attachments not recommended by the appliance manufacturer as they may cause hazards.

22. Replacement parts – When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original parts. Unauthorized substitutions may result in fire, electric shock, or other hazards.

23. Safety check – Upon completion of any service or repairs to this appliance, ask the service technician to perform safety checks to determine that the appliance is in proper operating condition.

Notes:


1. Item 3 is not required except for grounded or polarized equipment.
2. Item 17 and 18 are not required except for units provided with antenna terminals.
3. Item 17 complies with UL in the U.S.A.

Before operation

Notes on cassette tape


Safety tab (accidental erasure prevention tab)

After an important recording has been finished, break the safety tab, to prevent the recorded contents from being erased or recorded on accidentally.





To store cassette tapes

Do not store the tapes in a place which is subject to direct sunlight, or near equipment that generates heat. Keep the cassette tapes away from any magnetic field.



When there is slack in the tape

In such a case, insert a pencil into the reel hole and wind the reel hub to remove the slack.



Notes:


1. 120-minute cassette tape

Since a 120-minute cassette tape is very thin, the tape could adhere to the pinch roller or be easily cut. It is recommended that these tapes not be used with this unit to prevent possible damage.

2. Endless tapes

Do not use an endless tape, as this could damage the mechanism of the unit.

Cleaning the head section



Cleaning the heads and peripheral components

For maintaining the best condition of the deck and for longer service life, always keep the head (recording/playback/erase), capstan and pinch roller clean. To clean them, perform the following:

1. Open the cassette holder.
2. Using a cotton swab dipped in alcohol, clean the head (recording/playback/erase), capstan and pinch roller carefully.

Demagnetizing the head

When the recording/playback head is magnetized, the sound quality will be deteriorated. In such a case, demagnetize the head using a commercially available demagnetizer (head eraser).

Note:

There are precisely aligned parts around the heads, including the tape guides. When cleaning, pay special attention so as not to apply shock to them.

Beware of condensation

When water vapor comes into contact with the surface of cold material, water drops are produced.

If condensation occurs, correct operation may not be possible, or the unit may not function correctly.






This is not a malfunction, however, and the unit should be dried. (To do this, turn the POWER switch ON and leave the unit as it is for several hours.)

Be specially careful in the following conditions:

- When the unit is brought from a cold place to a warm place, and there is a large temperature difference.
- When a heater starts operating.
- When the unit is brought from an air-conditioned place to a place of high temperature with high humidity.
- When there is a large difference between the internal temperature of the unit and ambient temperature, or in conditions where condensation occurs easily.

Controls and indicators


Figure shows the KX-7050.



System connections

Make connection as shown below. When connecting the related system components, refer also to the instruction manuals of the related components.

Do not plug in the power lead until all connections are completed.




STAND BY mode of POWER switch

When the power cord of this system is plugged into an AC outlet, the STAND BY indicator lights up regardless of the ON/OFF setting of the POWER switch. This indicates that a small amount of current is being supplied to the unit to back up the memory contents. This mode is referred to as the Stand By mode.

Notes:



1. Connect all cords firmly. If connections are loose there could be loss of sound or noise produced.
2. When plugging and unplugging connection cords be sure to first remove the power cord from the AC outlet. Plugging/unplugging connection cords without removal of the power cord can cause malfunctions or damage to the unit.



Note on SYSTEM CONTROL jack

Various system operations are available by connecting this jack to a KENWOOD amplifier or CD player equipped with a SYSTEM CONTROL jack.

Do not connect this jack to other equipment than specified by us, otherwise malfunction may result.



- Insert the plug of each system control cord securely until the root.

SYSTEM MODE selector switch

When this unit is connected to the SYSTEM CONTROL jack of a KENWOOD amplifier (receiver) via a system control cord, set this switch according to the functionality or operating procedure of the amplifier (receiver).

"XS" position

Set the switch to this position when the audio cords are connected to the TAPE 1 or TAPE B jacks of an amplifier (receiver) with the XS mark.

"XS" position

Set this switch to the XS position in the following cases.

When this unit is connected to an amplifier (receiver) with the XS mark.

When this unit is connected to an amplifier (receiver) with the XS mark and the audio cords are connected to other jacks than TAPE 1 and TAPE B.

- If the switch is set to XS position while the audio cords are connected to the TAPE 2 (MONITOR) jacks of an amplifier (receiver) equipped with the monitor function, monitoring during recording will not be available.
- Before changing the system mode, be sure unplug the power cord from the power outlet.

System operations

Connection with an amplifier

The SYSTEM CONTROL jacks of KENWOOD amplifiers are marked either XS or XS.

The following operations are respectively available by connecting this unit to an amplifier via a system control cord.

XS type jack: Systematic remote control using the remote control unit provided with the amplifier is available.

XS type jack: Both systematic remote control and "Easy Operation" are available.

For details, please read the instruction manual supplied with the amplifier (receiver).

Connection with a CD player

The "CD PEAK SEARCH recording" is available when this unit is connected to a CD player with the XS mark via a system control cord.

For details, please refer to page 19.


Listening to cassette tapes

Before starting playback.

- ① Set the **TIMER** switch to **OFF**.




- ② Set the **POWER** switch to **ON**.



■ To playback a tape

1 Insert a cassette tape.

Press the **OPEN/CLOSE** key.




- The type of tape, Normal, Chrome or Metal, is detected and set automatically.
- This unit incorporates a mechanism which automatically removes the slack of tape inserted. However, it is still recommended to remove the tape slack as far as possible before inserting it in the deck.


Close securely by pressing the **OPEN/CLOSE** key.

2 Determine the playback conditions.

Select the **Dolby NR** mode.





Select according to the tape to be played.



The indication changes every time the key is pressed.


3 Start playback.



To stop playback, press the  key.


Listening through headphones

Insert the plug of the commercially available headphones into the **PHONES** jack and adjust the sound level with the **PHONES LEVEL** control.




■ Fast Forward and Rewind

1 Stop playback.




2 Press the ◀◀ key or ▶▶ key.



◀◀ : Rewound in the
← direction

▶▶ : Fast forwarded
in the → direction

To stop the Fast Forward or Rewind operation



■ Index scan


Index scan plays the first about 10 seconds of every tune on tape.

Press the INDEX SCAN key




INDEX
SCAN
Blink

To cancel Index scan



• Normal playback starts.




• Playback stops.

■ A/B repeat


A/B repeat plays the block between two designated points repeatedly.

This function is activated during playback.

1 Register start point A.




2 Register end point B.




- Leave an interval of more than 10 seconds after registering start point A.
- A/B repeat starts automatically.
- After repeating playback 16 times, normal playback resumes.
- The counter shows the total number of repetition.

To cancel A-B repeat mode.

To resume normal playback mode



To stop playback





DPSS operation

The DPSS (Direct Program Search System) enables the following convenient operations according to the instructions of the operation keys.



The DPSS functions are based on the detection of non-recorded spaces of 4 seconds or more between tunes.

1. Skip play: By specifying a tune located several tunes beyond (or behind) the tune being played, skips tunes between the current tune and the selected tune and starts playback from the beginning of the selected tune. Up to 16 tunes can be skipped in Skip Search.
2. Single-tune repeated playback: One single tune is played back repeatedly up to 16 times.
3. Rewind & Play: Rewinds the tape to the beginning and starts playback from there.
4. Dash & Play: If a non-recorded space of more than 10 seconds is detected during playback, that space will be skipped by fast forward tape winding.





■ Skip play operation

To play a tune located immediately after the tune being played:





Press once during the playback.

To play the tune being played from the beginning:





Press once during the playback.

To play a tune located 4 tunes beyond:



Press 4 times during the playback.

To play the tune located 4 tunes behind:




Press 5 times during the playback.

Index scan and DPSS will not function properly with the following types of tapes.

- Tapes containing spaces of 4 seconds or more, such as conversations and speeches.
- Tapes containing extremely low levels or non-recorded spaces in the middle of tunes, such as classical music.
- Tapes containing recording of large noise between tunes.
- Tapes recorded with low recording level.
- Tapes recorded using Cross-fade recording.

■ Rewind & Play operation




Press simultaneously.

■ Dash & Play operation

The Dash & Play skips long non-recorded spaces automatically as the tape is played.

Press the and keys simultaneously.



During first playback

MULTI WAY COUNTER

1

During 16th playback

MULTI WAY COUNTER


16

- After repeating Dash & Play 16 times, the unit enters the stop mode.

■ Single-tune repeated playback operation

1 Play the tune to be repeated.

2 Press the play key.



During first playback

MULTI WAY COUNTER

1


During 16th playback

MULTI WAY COUNTER

16

- Normal playback resumes after repeating the same tune for 16 times.



■ To cancel the playback above in the middle



Press once.

■ Zero-stop operation

Press simultaneously.



- After fast forwarding or rewinding tape until the counter reading of 0.00, then the unit enters the stop mode.

Usage of counter

Before starting recording (Playback), press the **COUNTER RESET** key to reset the counter to "0.00", and write down the counter reading when the recording (Playback) should be stopped in the middle of the tape, etc.; this will make it easy to locate the same position when you want to continue recording (Playback) next time.

DISPLAY key

Every time the **DISPLAY** key is pressed, the displays change as follows:

Normal lighting → Counter lighting → All OFF

DISPLAY



How to record

The cassette deck incorporates the **Dolby HX Pro** headroom extension function and **ATCS** function to provide a recording with superior high-frequency characteristics.

Dolby S NR

(KX-7050S only) : The Dolby S type NR is a noise reduction system for high-quality sound reproduction. It is a consumer system developed based on the principle of the Dolby SR used in professional audio.


ATCS : The ATCS stands for Automatic Tape Calibration System. This function optimizes the bias and recording sensitivity values automatically in order to make the full use of the characteristics of the tape to be used in recording.

Preset function : The optimum values for recording, set by the ATCS, can be stored for each type of tape (Normal, CrO₂ and Metal). The stored optimum values can be recalled simply by pressing the PRESET key.


■ Optimum value preset operation

Preparation: Be sure to set the deck in the stop mode before entering the ATCS mode.

1 Insert a tape.




2 Press the ATCS key.




- The tape stops at a position a few seconds beyond the position where the key is pressed.

3 Store the values in preset memory.



- If bias and recording sensitivity values have already been preset, they are replaced by the new values.

■ To cancel or recall the preset values



- Each press the key turns the indicator ON and OFF alternately.
- When the indicator is OFF, the bias value and recording sensitivity value returns to the initial values.

Recording with Dolby HX Pro

When recording is started with this unit, the Dolby HX Pro headroom extension function automatically operates to provide a recording with superior high-frequency characteristics.

What is Dolby HX Pro


In ordinary recording using high-frequency biasing, the high-frequency bias current, which should be constant, is increased with some recording sources due to the high-frequency component contained in the music, etc. This increase affects the recording characteristics with distorted high frequencies and degraded dynamic range and frequency response.

The Dolby HX Pro circuit detects the high-frequency component contained in the music source being recorded, and reduces excessive bias current to make it constant. As a result, the recording characteristics of high frequencies are drastically improved, and the improved high-frequency reproduction can also be enjoyed even when the tape is played on tape decks which are not equipped with circuit.

How to cancel ATCS operation


During adjustment

(ATCS indicator blinking)



After adjustment

(ATCS indicator in steady lighting)




- The ATCS is not canceled even when the OPEN/CLOSE key is pressed.

The cassette deck incorporates the Dolby HX Pro headroom extension function and ATCS function to provide a recording with superior high-frequency characteristics.


■ How to record

1 Set up the cassette deck.


- ① Insert a tape.



- ② Select the Dolby NR mode.




- ③ When recording tuner sound




- To cancel, press the MPX FILTER key again.

2 Select the source to be recorded.

3 Activate ATCS setting.



or




- For the optimum value preset operation, refer to page 14.
- Recording is possible even when the ATCS setting operation is omitted, but the recorded tone may be altered with some tapes.

4 Set the recording level.

- ① Play a music source.

- ② Enter the record-pause mode.



Press both keys at the same time.

- ③ Adjust the recording balance and recording level.




- Adjust so that segments around the 0 dB segment of the peak level meter, light up at times.

- ④ Stop playing the source.

5 Start recording.

- ① Play the music source from the beginning.

- ② Press the key.



Press once.

- The deck enters the stop mode automatically when the tape has been recorded till the end.

Dolby noise reduction system

The Dolby noise reduction system was developed to reduce the tape hiss noise generated during playback.

The optimum effect of the Dolby NR system is obtained when the same type NR system is used for both recording and playback. If a different type NR system is used, playback is not performed correctly. Make sure that the same type noise reduction system is used for both recording and playback.

It is recommended that tapes recorded with Dolby NR be marked "B", "C" or "S" so that the Dolby NR system used in recording can easily be distinguished.

Dolby B NR

The most popular noise reduction system used in home audio components. Usually, Dolby NR system corresponds to B NR.


Dolby C NR

Dolby C NR offers improved noise reduction performance over that of the Dolby B NR.


Dolby S NR (KX-7050S only)

This is the latest Dolby NR system featuring improvement in noise in the high and low frequencies. As, in human audition, it is compatible with Dolby B NR, tapes recorded with Dolby S NR can be played on ordinary car stereo and headphone stereo with Dolby B NR.

■ To pause recording temporarily


• The  indicator lights up.

To resume recording



■ To stop recording


1




2 Stop playing the source component.

■ How to provide non-recorded blanks between programs


To make a non-recorded blank of about 4 seconds


Press the  key twice in succession.



• After leaving a non-recorded blank of about 4 seconds, the deck enters the record-pause mode.

To make a non-recorded blank during recording

Press the  key once during recording.




• After running to make a non-recorded blank of about 4 seconds from the point where the key is pressed, the deck enters the record-pause mode.

■ To re-start recording after mistake


A non-recorded space of 4 seconds or more should be reserved before the position where recording was started.


1 Stop recording and rewind tape.




• Recording stops, tape is rewound until the position where the recording was started and the deck enters the record-pause (REC PAUSE) mode after creating a non-recorded space of about 2 seconds after the previous tune.


2 Re-start recording.

① Press the  key twice.



• The deck enters the record-pause mode after creating a non-recorded space of 4 seconds.

② Press the  key once.



• Recording starts.

Notes on the TAPE/SOURCE switching (AUTO MONITOR)


Every time the AUTO MONITOR key is pressed, the TAPE and SOURCE indicators light up alternately.

- When the SOURCE indicator is lit The sound of the source (signal source selected by the input selector switches of the amplifier, such as tuner, CD, turntable and DAT) is reproduced from the speakers or headphones.
- When the TAPE indicator is lit The tape playback sound (if it is during recording, this refers to the sound played immediately after the source sound is recorded on tape) can be monitored.

Whenever recording or playback is started, the SOURCE indicator being lit goes off and the TAPE indicator lights up.

Synchro recording

By connecting this unit with a KENWOOD XS type amplifier (receiver) with a SYSTEM CONTROL jack and a KENWOOD turntable with a SYSTEM CONTROL jack using system control cords, recording on this unit and playback on the turntable can be started simultaneously.




■ Synchro recording of analog disc

1 Set the input selector switches of the amplifier for the PHONO source.


2 Place an analog disc on the turntable.

3 Make preparations for recording.

① Insert a tape.



② Select the Dolby NR mode.



4 Activate ATCS setting.


Recording is possible even when ATCS setting is omitted.




- For the bias preset operation, refer to page 14.

5 Adjust the recording level.

① Start playing an analog disc.




② Set the record-pause mode.




Press both keys at the same time.

③ Optimize the recording balance and recording level.




④ Stop playing the analog disc.




- The cassette deck returns to the stop mode.

6 Set the record-pause mode.



7 Start playing the analog disc.




- Recording starts at this moment.
- When the turntable has completed the play, the deck stops recording and enters the stop mode.

To stop recording in the middle

Press the **PLAY/CUT** key of the turntable.

- If the stop key of the cassette deck is pressed, the cassette deck enters the stop mode but the turntable does not.

By connecting this unit with a **KENWOOD XS** type amplifier (receiver) with a **SYSTEM CONTROL** jack and a **KENWOOD** CD player with a **SYSTEM CONTROL** jack using system control cords, recording on this unit and playback on the CD player can be started simultaneously.



■ Synchro recording of CD


1 Set the input selector switches of the amplifier for the CD source.

2 Place a CD in the CD player.


- If your CD player can hold multiple discs, specify the disc number.

3 Make preparations for recording.

① Insert a tape.




② Select the Dolby NR mode.



4 Activate the ATCS setting.

Recording is possible even when ATCS setting is omitted.




- For the bias preset operation, refer to page 14.

5 Adjust the recording level.

① Play a CD.




② Set the record-pause mode.




Press both keys at the same time.

③ Optimize the recording balance and recording level.




④ Stop playing the CD.



- The cassette deck returns to the stop mode.

6 Set the record-pause mode.



7 Start playing the CD.



- Recording starts at this moment.
- When the CD player has completed playback, the deck stops recording and enters the stop mode.

To stop recording in the middle

To pause.....Press the key of the CD player.


To restart

recording.....Press the key of the CD player.

To stop.....Press the key of the CD player.

- If the stop key of the cassette deck is pressed, the cassette deck enters the stop mode but the CD player does not.

Recording of CD playback




■ CD peak-search recording

1 Set the input selector switches of the amplifier for the CD source.


2 Place a CD in the CD player.

3 Make preparations for recording.

① Insert a tape.



② Select the Dolby NR mode.





(With the KX-7050S, [S] also lights.)

4 Search the peak value on the CD.




- When this unit is connected to KENWOOD DP-R791, press the SPEED key so that the SPEED indicator goes off.
- When performing CD PEAK SEARCH recording with a CD player which can be loaded multiple compact discs, set the CD player to TRACK mode, press the disc select key and press the CD PEAK SEARCH key.
- The cassette deck enters the record-pause mode.
- Sound sampled from the CD is played back.
- If the CD player is not connected to this unit via a system control cord, the CD peak search function will be canceled in about 30 seconds.

5 Set the recording balance and recording level.



Adjust so that the segments around 0 dB light sometimes.

6 Start recording.



- The CD player starts playback, and the cassette deck starts recording.

To stop in the middle


To pause..... Press the key of the CD player.

To restart

recording... Press the key of the CD player.

To stop..... Press the key of the CD player.

- If the stop key of the cassette deck is pressed, the cassette deck enters the stop mode but the CD player does not.




■ Edited recording of CD

1 Set the input selector switches of the amplifier for the CD source.


2 Place a CD in the CD player.

3 Make preparations for recording.

① Insert a tape.



② Select the Dolby NR mode.



4 Start editing.


- For the editing method, read the instruction manual of the CD player.

5 Search the peak value on the CD.




- The cassette deck enters the record-pause mode.
- Sound sampled from the CD is played back.
- If the CD player is not connected to this unit via a system control cord, the CD peak search function will be canceled in about 30 seconds.

6 Set the recording balance and recording level.



7 Record onto cassette tape side A.




- After side A has been recorded, the cassette deck enters the stop mode and the CD player enters the pause mode.

8 Record onto side B of the tape.

① Reverse the cassette tape.

② Press the key of the cassette deck.



③ Press the key of the CD player.

Timer operations


This unit incorporates a built-in timer standby function. By using an audio timer optionally available in the market, wake-up playback and unattended recording of tape can be started at any time of the day.

Preparations for timer playback and recording

Connect the power cords of the components directly or indirectly to the timer so that their powers can be turned on via the timer.

The timer setup operation varies depending on the timer. Also read carefully the instruction manual of your audio timer.


When operating the unit other than CD player using an audio timer, be sure to remove the disc from the CD player.



■ Timer playback

1 Set the power switches of the components used in timer playback to ON.


2 Insert a cassette tape.



- The type of tape, that is, Normal, Chrome or Metal, is set automatically.
- Remove the tape slack before insertion.

3 Set the playback condition.

Select the Dolby NR mode.



(With the KX-7050S, [S] also lights.)

- Set according to the tape to be played.

4 Start playback.

5 Adjust the volume of the amplifier.


6 Rewind the tape to the start position.

7 Set the timer so that the tape starts at the desired time of the day.

8 Set the TIMER switch to PLAY.



- When the set time comes, tape playback starts automatically.
- Playback stops when the end of tape is reached.




■ Timer recording of tuner broadcast

1 Set the power switches of the components used in timer recording to ON.


2 Receive the desired radio station with the tuner.

3 Make preparations of the cassette deck.


① Insert a tape in a cassette deck.



② Select the Dolby NR mode.




③ Set the MPX FILTER to ON.



- To cancel, press the MPX FILTER key again.


4 Activate ATCS setting.



- For the preset operation, refer to page 14.

5 Adjust the recording level.

① Set the record-pause mode.



Press both keys at the same time.

② Optimize the recording balance and recording level.



- Adjust so that the 0 dB segments of the peak level meter lights at times.

6 Set the amplifier volume to the minimum position.

7 Set the time when the recording is to be started.

- For the time setup operation, read the instruction manual of your timer.

8 Set the TIMER switch to REC.




- When the set time comes, the powers of the related components are turned ON and recording starts.
- Recording stops when the end of tape is reached.

Note:

To ensure that the cassette deck's automatic shut off switch operates before the power is shut off, set the timer so that it operates for a little longer than the playing time of the tape.

Remote control operation (optional)

This unit can be controlled from the optional remote control unit. The functions of the keys on the remote control unit are the same as those of the keys with the same names on the main unit.




Model: RC-X090
Infrared system

* IMPORTANT


This option may not be available in some areas.
For details on options, consult your dealer.

■ Loading batteries

1 Remove the cover.




2 Insert batteries.




Insert two AA-size (R6/SUM-3) batteries as indicated by the polarity marking.

3 Close the cover.



■ Operation procedure

Operating range



- When two operation keys on the remote control unit are pressed successively, press each key securely reserving an interval of more than 1 second for each press.

Notes:

1. The supplied batteries are intended for use in operation checks. Therefore, their lives may be shorter than ordinary batteries.
2. When the remote-controllable distance gets shorter than before, replace both batteries with new ones.
3. Malfunction may occur if direct sunlight or the light of a high-frequency lighting fluorescent lamp enters the remote control light sensor. In such a case, change the system installation position to prevent the malfunction.

In case of difficulty

What appears to be a malfunction may not always be serious. If your unit should not perform as expected, consult the table below to see if the problem can be corrected before seeking help from your dealer or service representative.

Symptom	Cause	Remedy
Sounds is not produced when the Play key is pressed.	<ul style="list-style-type: none"> The connection cords are connected improperly. The head is dirty. Tape is irregularly wound and hard to take up. A non-recorded tape is being played. 	<ul style="list-style-type: none"> Connect the cords properly referring to "System connections". Clean the head referring to "Cleaning the head section". Replace the tape. Play a recorded tape.
The deck does not work when an operation key is pressed.	<ul style="list-style-type: none"> The cassette holder is not closed completely. The operation key was pressed immediately after closing the cassette holder. The operation key was pressed within less than 4 seconds after the power was turned on. Tape is not inserted. Tape is irregularly wound and hard to take up. Tape has been fully wound to reel. 	<ul style="list-style-type: none"> Close the cassette holder completely. Press the desired operation key in a few seconds after closing the cassette holder. Press the desired operation key in more than 4 seconds after turning the power on. Insert a tape. Replace the tape. Change the tape transport direction or insert the tape inversely.
DPSS malfunctions.	<ul style="list-style-type: none"> The tape is not suitable for DPSS operation, for example the spaces between tunes are too short. 	<ul style="list-style-type: none"> Read "DPSS operation".
CD PEAK SEARCH does not work.	<ul style="list-style-type: none"> A disc is not placed in the CD player. The disc is dirty. 	<ul style="list-style-type: none"> Place a disc in the CD player and press the CD PEAK SEARCH key. Clean the disc, place it in the CD player, and press the [CD PEAK SEARCH] key.
The cassette holder does not open when the OPEN/CLOSE key is pressed.	<ul style="list-style-type: none"> The key is pressed during recording. 	<ul style="list-style-type: none"> Press in the Stop mode.
Sound is hoarse, or high frequencies are not audible.	<ul style="list-style-type: none"> The head is dirty. The tape is stretched or wrinkled. 	<ul style="list-style-type: none"> Clean the head referring to "Cleaning the head section". Replace the tape.
Sound is distorted.	<ul style="list-style-type: none"> The recording level was too high. A tape recorded with distorted sound is being played. 	<ul style="list-style-type: none"> Adjust the recording level referring to "How to record". Replace the tape.
Recording is not initiated when the REC key is pressed.	<ul style="list-style-type: none"> The protection tab on the cassette has been broken. The cassette holder is not closed completely. The recording level is set to the minimum position. The TAPE A or B input selector is selected on the amplifier. Tape is wound to one side. 	<ul style="list-style-type: none"> Use a cassette with unbroken tab. or close the hole. Close the cassette holder completely. Adjust the recording level referring to "How to record". Press the input selector key of the source to be recorded. Insert the tape inversely.

Symptom	Cause	Remedy
Noise level is high.	<ul style="list-style-type: none"> • The head is magnetized. • External noise is induced. • The recording level was too low. 	<ul style="list-style-type: none"> • Demagnetize the head referring to "Cleaning the head section". • Install the system apart from other electrical appliances and TV set. • Adjust the recording level referring to "How to record".
High frequency sound is slightly enhanced.	<ul style="list-style-type: none"> • A tape recorded with Dolby NR ON is being played with Dolby NR OFF. 	<ul style="list-style-type: none"> • Press the [DOLBY NR] switch to B or C. (With the KX-7050S, set to B, C or S.)
Sound is vibrating.	<ul style="list-style-type: none"> • The capstans or pinch rollers are dirty. • Tape is irregularly wound. 	<ul style="list-style-type: none"> • Clean the head referring to "Cleaning the head section". • Wind the tape regularly by fast forwarding, rewinding or playing it fully from one reel to another.
Playback or recording starts immediately when the power is switched ON.	<ul style="list-style-type: none"> • The TIMER switch is set to PLAY or REC. 	<ul style="list-style-type: none"> • Set the TIMER switch to OFF unless timer playback or timer recording is required.

Notes:

1. This unit is microprocessor-controlled, so malfunction may occur due to external noise or interference noise. In such a case, unplug the power cord, plug it and turn power on again.
2. Do not use contact cleaners because it could cause a malfunction. Be specially careful against contact cleaners containing oil, for they may deform the plastic components.
3. With some tapes, a squeaky noise is produced when the tape is stopped automatically. This is due to the tape protection function, and not a malfunction.
4. Do not use 120-minute tapes, for the tape is too thin and gets easily tangled.

Specifications

KX-7050

Track System	4-track, 2-channel stereo
Recording System	AC bias (Frequency: 210 kHz)
Heads	Playback/recording head (Combination head)
	1
	Erasing head
	1
Motors	DC motor × 3
Fast Winding Time	Approx. 90 seconds (C-60 tape)
Frequency Response:	
Normal Tape	20 Hz to 18,000 Hz, ± 3 dB
CrO ₂ Tape	20 Hz to 19,000 Hz, ± 3 dB
Metal Tape	20 Hz to 20,000 Hz, ± 3 dB
Signal-to Noise Ratio:	
Dolby C NR ON	76 dB (Metal tape)
Dolby B NR ON	67 dB (Metal tape)
Dolby NR OFF	59 dB (Metal tape)
Harmonic Distortion	Less than 1.6%
(at 315 Hz, 3rd H.D. 250 nWb/m Metal Tape)	

Wow and Flutter 0.055% (W.R.M.S.)
±0.16% (DIN)

Input sensitivity/Impedance:

LINE IN 100 mV/47 kΩ

Output Level/Impedance:

LINE OUT..... 775 mV/1 kΩ

Headphones..... 2.3 mW/32 Ω

[GENERAL]

Power Consumption 36 W

Dimensions..... W: 440 mm (17-5/16")

H: 127 mm (5")

D: 326 mm (12-13/16")

Weight (Net)..... 5.4 kg (11.9 lb)

KX-7050S

Track System	4-track, 2-channel stereo
Recording System	AC bias (Frequency: 210 kHz)
Heads	Playback/recording head (Combination head) 1 Erasing head..... 1
Motors.....	DC motor×3
Fast Winding Time	Approx. 90 seconds (C-60 tape)
Frequency Response:	
Normal Tape.....	20 Hz to 18,000 Hz, ±3 dB
CrO ₂ Tape	20 Hz to 19,000 Hz, ±3 dB
Metal Tape	20 Hz to 22,000 Hz, ±3 dB
Signal-to Noise Ratio:	
Dolby S NR ON.....	81 dB (Metal tape)
Dolby C NR ON.....	78 dB (Metal tape)
Dolby B NR ON.....	69 dB (Metal tape)
Dolby NR OFF.....	60 dB (Metal tape)
Harmonic Distortion.....	Less than 1.1% (at 315 Hz, 3rd H.D. 250 nWb/m Metal Tape)

Wow and Flutter..... 0.055% (W.R.M.S.)
± 0.16% (DIN)

Input sensitivity/Impedance:

LINE IN 100 mV/47 k Ω

Output Level/Impedance:

LINE OUT 775 mV/1 k Ω

Headphones..... 2.3 mW/32 Ω

[GENERAL]

Power Consumption 36 W

Dimensions..... W: 440 mm (17-5/16")

H: 127 mm (5")

D: 326 mm (12-13/16")

Weight (Net)..... 5.8 kg (12.8 lb)

Note:

KENWOOD follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.

**For CANADA
DOC REGULATION**

"This digital apparatus does not exceed the CLASS B limits for radio noise emissions from digital apparatus as set out in the radio interference regulations of the Canadian Department of Communications."

**For the U.S.A.
FCC WARNING**

This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment may cause harmful interference to radio communications, if it is not installed and used in accordance with the instructions. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.